Photo Booth

Capture and merge selfies into a single picture.

After the first shot, the camera takes three more selfies with two-second intervals. You can strike a different pose each time.



Hands-free image capture

Flash a smile, and the camera instantly captures your smiling face. Or, just say "Say Cheese"!



Find More Information

- On your phone: Apps > Device Help
- On the web: att.com/DeviceHowTo

Manage Your Account

On your phone: Apps > myAT&T



On the web: att.com/MyATT Note: You can also suspend service if your phone is stolen

Give us a Call

- 800.331.0500
- 611 from any AT&T wireless phone

Accessories

- att.com/WirelessAccessories
- Visit your AT&T store. Note: Use only the included charger and cable with your device.

Coverage not available in all areas. Some features may require monthly access and/or per use charges. Visual and screen images are simulated. Contains Li-polymer battery recycle or dispose properly. HTC, the HTC logo, HTC Desire, and HTC BlinkFeed are trademarks of HTC Corporation. All other marks contained herein are property of their respective owners. ©2014 AT&T Intellectual Property. All rights reserved. AT&T, the AT&T logo and all other AT&T marks contained herein are trademarks of AT&T Intellectual Property.

□TC Desire EYE



Need More Help?

Quick Start



Need more help? Go to Apps > Device Help

HTC BlinkFeed®

Easily access content from popular websites and your social networks.

- From the Home screen, swipe right to access HTC BlinkFeed.
- 2. In HTC BlinkFeed, swipe right to open the slideout menu.
- Tap > Add content.
- 4. Tap a category to see available
- 5. Select the content you want to add to the feed.



Turn off HTC BlinkFeed

- From the Home screen, swipe right to a panel with a blank area.
- 2. Press and hold the blank area to access customization options.
- Tap Manage home screen pages.
- 4. Swipe to the HTC BlinkFeed panel, and then tap Remove.

Tip: Checking Connections



Having trouble connecting to the Internet? Try these steps:



Tap ::: > Settings.



If Airplane mode is on, tap the Airplane mode On/ Off switch to resume data transmission



Wi-Fi can provide additional data coverage. Tap the Wi-Fi On/Off switch to turn it on.



- 4. Mobile data enables 4G LTE service. Tap the Mobile data On/Off switch.
- Did you set a data limit and exceed it? Tap More > Data Manager. Clear the Limit mobile data usage option.



Open the browser and go to a website to test if your data connection is working.

Tip: Optimize Battery Life

Switch to Power Saver or Extreme Power Saver Mode



- Tap **:::: > Settings >** Battery Manager. Tap the **Power saver** or Extreme power saving mode switch to turn it on.
- These may reduce the usage of phone features but can extend battery life.

Note: See the User Guide for

Activate Automatic brightness



- Tap **;;;; > Settings > Display & gestures >** Brightness.
- With the Automatic brightness option selected, drag the slider to set the maximum brightness level.

Check which apps are using your battery the most



- Tap ::: > Settings > Battery Manager > Battery usage.
- You can disable or uninstall apps that you don't use.

AT&T Services



AT&T Ready2Go

Set up your email, social networking, Wi-Fi and more.



AT&T DriveMode® Stay safe while driving. Stops incoming calls and text.



AT&T Locker™ Cloud storage to store, sync, & share your photos, videos, and documents.





A secure and easy-to-use app to manage and access your passwords and user names from your mobile devices and computers.



AT&T Navigator®

Get traffic updates, GPS navigation and turn-by-turn voice directions.



Mobile TV Watch LIVE, on-demand and downloadable mobile TV including ESPN Mobile TV, Fox



YPmobile®

News and more.

Use text or voice search to find businesses and events near your location.

Data usage and subscription charges may apply.